

How to use

IN FRANCE

Moisten the sponge or dishwashing brush then rub the soap. Scrub the dishes and rinse.

IN STOCK

Tip

Soak the dishes first. Then let tap water run over the soap, the soapy water will help degrease more quickly.



04 90 73 29 86 contact@savonnerie-alpilles.fr www.savonnerie-alpilles.fr

97% INGREDIENTS OF NATURAL ORIGIN



IT HAS TO SHINE!

Available sizes: 100 g rectangle, 100 g square, 100 g cube, 125 g rectangle, 150 g rectangle, 200 g rectangle, 250 g rectangle, 25 g square, 50 g square, 100 g round, 150 g round.

FRAGRANCE

of your choice

ACTIF

White vinegar

Descaler and degreaser

Very effective for cleaning and making dishes shine.

COMPOSITION

+30% soap – contains orange essential oil : limonene

PACKAGING OPTIONS

Scabbard Personalized cardboard box Without packaging Shrink film

CONDITIONING

38 per carton (in stock)